



<b>Instruction sheet x-shield</b>	
<b>Subsoil</b>	The subsoil has to be prepared similar to the installation of a decorative wallcovering.
<b>Adhesive</b>	Use adhesive for flooring or other strong adhesive, high adhesion is needed
<b>Installation</b>	Apply the adhesive to the subsoil (suitable quantity). Press the x-shield-material into the adhesive, no bubbles shall be left. At all joints overlap the material approx. 2 cm.
<b>Earthing</b>	Use self adhesive coppertape, tiem no. 97406, stick it on the surface of the x-shield-material, use the coppertape once around the room and connect it to a suitable earthing.
<b>Warning</b>	Earthing connections shall be done be authorised specialists only. Beside this guideline all valid national standards and regulations as well as the standards rules of technique have to be observed.