

Instruction sheet EMC protect	
Subsoil	The subsoil has to be prepared similar to the installation of a decorative wallcovering.
Adhesive	Use dispersion-adhesive or similar.
Installation	Apply the adhesive to the subsoil (suitable quantity). Press the EMC protect-material into the adhesive, no bubbles shall be left. At all joints overlap the material approx. 2 cm.
Earthing	Use self adhesive coppertape, tiem no. 97406, stick it on the surface of the EMC protect-material, use the coppertape once around the room and connect it to a suitable earthing.
Warning	Earthing connections shall be done be authorised specialists only. Beside this guideline all valid national standards and regulations as well as the standards rules of technique have to be observed.